

ISSUE 792 NOVEMBER 2018	Clean Weapons Before Using Solid Film Lubricant 36-37 Weapons Inspection Before and After Transfer 38 M16-Series Rifle, M4/M4A1 Carbine:
COMBAT VEHICLES 2	Front Sight Tool, Fabricate or Order 38 M2A1 Machine Gun, Breech Lock Selection Tool Instructions Corrected 39
M88A2 Recovery Vehicle, Tow Bar Inspection 2	M2A1 Machine Gun, Barrel Locking Spring NSN 39
M88A2 Recovery Vehicle, Heater Exhaust Tube Clamp 3	M240B, M240L Machine Guns, Buffer Checks 40
M113A2/A3 FOV, Exhaust Grille Cover 4 Stryker, EA Seatbelt Damage 5 Stryker Towing Instructions 6-7	TOOLS 41
Stryker, Brake Reservoir Draining Stops Corrosion 7	SATS PM Tips 41-43
Stryker, Engine Oil Copper Levels 8-9	<i></i>
AVLB Transmission Filter Housing, Drain Plug Torque 9	MISSILES 44
TACTICAL VEHICLES 10	HIMARS, MLRS Cable Cleaning, Adapter Javelin Missile System, BB-2590 Damages CLU 44-45
Rust Busters Tip of the Month 10-11	Javellii Missile System, bb-2550 Damages CLO 45
Winter Weather Prep 12 HMMWV Front Bumper, Lifting Shackle Parts Fix 13 FMTV, CTIS Air Hose Leak Identification 14-15	SOLDIER SUPPORT 46
GCSS-Army Corrosion Code 15	LADS, Drain Water During Cold Weather 46-47
LMTV Hydraulic Tank NSN 15	Soldier Enhancement Program (SEP) Info 48-49
	Equipment Data Plates Aid Readiness 50-51
CONSTRUCTION 16	© COMMUNICATIONS 54
Buffalo A2 Steering Fluid, Air Tank Draining 16	COMMUNICATIONS 51
Backhoe Loader, No Ether Spray for Engine Starts 17	OE-254 Mast Antenna Parts NSNs 51
(AVIATION 40	SINCGARS Cable Connections 52-53
AVIATION 18	
Aircraft Cold Weather Facts 18-23	LOGISTICS MANAGEMENT 54
SATS Leaf Spring Inspection Criteria 24-25	DC Managina Cubacina and Mada Fany 54-55
Aviation Corrosion Team Fmail 25	PS Magazine Submissions Made Easy

Aviation Corrosion Team Email **CREPS Reporting Website** 25 PEO Soldier Online Website, Social Media 25 RO-7B Shadow. Protection from the Elements 26 27-34 Moonbreaker, Part 2

56 PD TMDE, MSD Documents Move to milSuite 56-57 **TELS Hardware Supports GCSS-Army** 58-60 **Packaging Publications**

SMALL ARMS

M4/M4A1 Carbine: Use UOC for Parts Ordering

M240 Machine Gun, M16-Series Rifle,

TB 43-PS-792, The Preventive Maintenance Monthly, is an official publication of the Department of the Army, providing information for al Soldiers assigned to combat and combat support units and all Soldiers with unit maintenance and supply duties. All information published has been reviewed and approved by the agency responsible for the equipment, publication or policy discussed. Application of the information is optional with the user. Masculine pronouns may refer to both genders. The use of product or company names does not constitute endorsement of those products, services or companies by the U.S. Army. The use of non-DoD hyperlinks, along with their content, does not constitute endorsement by DoD or DA. Neither DoD nor DA exercises any editorial control over, and cannot vouch for, content on non-DoD websites.

PS, The Preventive Maintenance Monthly (ISSN 0475-2953)

is published monthly by the Department of the Army, Redstone Arsenal, AL 35898.

You are invited to send PS your ideas for improving maintenance procedures, questions on maintenance and supply problems and questions or comments on material published in PS.

Just write to:

MSG Half-Mast PS, the Preventive Maintenance Monthly **USAMC LOGSA (AMXLS-GP)** Bldg. 3303

Redstone Arsenal, AL 35898

Or email:

usarmy.redstone.logsa.mbx.psmag@mail.mil

Internet address:

https://www.logsa.army.mil/psmag/pshome.cfm

By Order of the Secretary of the Army:

Connie's Post Scripts

MARK A. MILLEY General, United States Army Chief of Staff

61

35


35

MARKE AVERILL cting Administrative Assistant to the Secretary of the Army

1822951








TOW BAR PM KEEPS RECOVERY ON TRACK







MAKE SURE THE PINTLE WORKS PROPERLY. IF IT LOOKS TOO WORN TO USE, ORDER A NEW PINTLE. IF IN DOUBT, ORDER A NEW ONE.

BETTER SAFE THAN SORRY!

ALSO, WHEN ATTACHING THE MI-SERIES TANK TOW FOOT CLEVIS, BE SURE THE CLEVIS LETTERING IS ON TOP WITH THE ARROW (TOW TOW THE ARROW TOWARD TOWARD TOWARD TOWARD TOWARD TOWARD TOWARD.






OPERATORS, MAKE SURE THE HEATER EXHAUST TUBE RUNNING BY YOUR M88A2'S AUXILIARY POWER UNIT (APU) IS **PROPERLY CONNECTED**. IF IT ISN'T, A FIRE COULD BREAK OUT EITHER DURING OR AFTER USING THE PERSONNEL HEATER.



Make sure personnel heater exhaust tube is connected...

....and cover is installed



WHILE
YOU'RE AT IT,
MAKE SURE
THE HEATER
EXHAUST TUBE'S
THERMAL
INSULATION
COVER IS
SERVICEABLE
AND IN PLACE.

RUNNING THE
HEATER WITHOUT
THE COVER
INSTALLED
CREATES A FIRE
HAZARD. REPLACE
A MISSING OR
DAMAGED COVER
WITH NSN 254001-533-3144.



ALSO, BE SURE
TO KEEP THE
BACK DECK
AREA WHERE
THE EXHAUST
COMES OUT
FREE OF TRASH
AND ANYTHING
ELSE THAT'S
FLAMMABLE.

LET'S GET YOU STARTED UP SO WE CAN START THE MISSION!



SOME DRIVERS LEAVE THE CANVAS COVER FOR THE MITSAZ/A3 INTAKE AND EXHAUST GRILLES IN PLACE WHEN STARTING THE ENGINE BECAUSE THEY THINK THAT'LL HELP THE ENGINE WARM UP FASTER WHEN IT'S COLD OUTSIDE.





THE COVER IS MEANT TO KEEP ICE, SNOW AND OTHER DEBRIS OUT OF THE ENGINE COMPARTMENT WHEN THE VEHICLE IS PARKED.

LEAVING THE COVER IN PLACE HEATS THE ENGINE TOO FAST. IT CAN EVEN BURN THE ENGINE UP. THAT'LL LAND YOU IN HOT WATER WITH YOUR COMMANDER AND COST YOUR UNIT SOME SERIOUS BUCKS.

ALSO


FUMES FROM THE ENGINE COMPARTMENT THAT WOULD NORMALLY BE VENTED THROUGH THE EXHAUST GRILLE ARE FORCED INTO THE DRIVER AND CREW COMPARTMENTS.

THAT CAN BE DEADLY.

ALWAYS ROLL THE COVER BACK FROM THE EXHAUST AND INTAKE GRILLES BEFORE STARTING YOUR VEHICLE.





Buckle Down on EA Seatbelt Damage



Crewmen, your Stryker's energy attenuating (EA) seats can save you from serious injury—or worse—during a blast from a mine or IED. But the EA seat, NSN 2540-01-633-6805, can't do its job if the four-point seatbelt, NSN 2540-01-671-1897, is damaged.

When exiting your vehicle through the lowered ramp door, be careful not to let the seatbelt harness fall to the floor. That can damage the seatbelt buckle.






The buckle can also fall into the crack between the ramp door and the vehicle hull. When the ramp closes...CRUNCH! Not only is the buckle damaged but maybe even the ramp door or hull.


So don't get in such a hurry that you neglect to keep those seatbelt buckles safe from damage. If you do, your Stryker could end up NMC!



REWMEN, IT'S VITAL THAT YOU CHECK OUT YOUR STRYKER'S -10 TM BEFORE TOWING TO ENSURE YOU DO IT THE RIGHT WAY. DOING IT WRONG RESULTS IN A DAMAGED VEHICLE.

IT COULD EVEN CATCH FIRE! JUST LIKE IT SAYS IN THE TM, THE BEST WAY TO FLAT-TOW A DISABLED STRYKER IS WITH ANOTHER STRYKER USING A TOW BAR.





ALWAYS BE SURE TO **DISCONNECT** THE TRANSFER CASE AND **RELEASE** THE PARKING BRAKE ON THE **DISABLED** VEHICLE **BEFORE** TOWING.



Make sure parking brake on disabled vehicle is disengaged


YOU CAN VERIFY THAT THE TRANSFER CASE IS DISCONNECTED BY REMOVING THE #4 ENGINE ACCESS PANEL. THEN USE YOUR HAND TO ROTATE THE DRIVE SHAFT TO MAKE SURE IT SPING FREELY WITHOUT BINDING. IF THE SHAFT BINDS AND DOESN'T SPIN FREELY, TRY AGAIN TO DISENGAGE THE TRANSFER CASE.

YOU NEED TO FOLLOW ALL OF THE TOWING PROCEDURES EXACTLY AS THEY'RE SHOWN IN THE -10 TM. THAT WAY YOU CAN'T GO WRONG! AND REMEMBER THAT IF A STRYKER IS SO DAMAGED IT CAN'T BE FLAT-TOWED, MECHANICS SHOULDN'T USE A HEMTT WRECKER TO TOW WITH THE STRYKER'S FRONT END SUSPENDED.

NOT ONLY WILL TOWING A STRYKER WITH THE FRONT END SUSPENDED DAMAGE THE REAR SUSPENSION AND HUBS ON THE STRYKER, BUT IT CAN ALSO BREAK THE HEMTT'S LIFT CYLINDERS. INSTEAD, CALL FOR AN M916 TRACTOR TRUCK WITH AN M870AI SEMITRAILER.


FOR MORE INFORMATION ON STRYKER TOWING,
CHECK OUT TACOM MAINTENANCE ACTION MESSAGE #18-007 AT:
https://tulsa.tacom.army.mil/Maintenance/message.cfm?id=MA18-007.html

Stryker... PUT BRAKES ON VALVE CORROSION



Crewmen, your Stryker's parking brake can fail if the front and rear service brake reservoirs aren't drained after every operation.


If you don't drain the reservoirs, moisture gets inside the parking brake valve and corrodes it. So make draining them a regular part of after-operations PMCS. The -10 TM shows you how to do it right.



The valve can also corrode if it's exposed to water when you wash your vehicle. Be sure to avoid spraying water directly on the valve. Better yet, cover it before washing your Stryker.

THE PARKING
BRAKE VALVE
CORRODES
WHEN WET OR
IF SERVICE BRAKE
RESERVOIRS AREN'T
PRAINED AFTER
OPERATIONS.





I GOT THE
RESULTS BACK
FROM MY
STRYKER'S ARMY
OIL ANALYSIS
PROGRAM (AOAP)
SAMPLE.

IT SHOWS THAT
THE ENGINE OIL
HAG ELEVATED
LEVELS OF
COPPER. SHOULD
I BE WORRIED?



NOT NECESSARILY! AN AOAP ANALYSIS
THAT SAYS ELEVATED COPPER LEVELS
IN YOUR STRYKER'S ENGINE OIL
"EXCEEDS WEAR METAL LIMITS" ISN'T
ALWAYS REASON FOR CONCERN.
A NEW ENGINE OIL COOLER COULD
BE TO BLAME.



DEPENDING ON THE CIRCUMSTANCES, THERE MIGHT ACTUALLY BE LITTLE PANGER OF EXCESSIVE WEAR AND/ OR COMPONENT FAILURE. BUT YOU NEED TO UNDERSTAND WHY ELEVATED COPPER LEVELS SOMETIMES HAPPEN BEFORE YOU SUBMIT ANOTHER— MAYBE UNNEEDED—AOAP SAMPLE.



BOTH THE STRYKER CAT C7 AND 3126 ENGINES HAVE AN INTERNAL ENGINE OIL COOLER WITH COPPER TUBES. WITH A **NEW** OIL COOLER, COPPER DISSOLVES FROM THE SURFACE OF THE OIL COOLER TUBES AND LEACHES INTO THE ENGINE OIL.

AS THE OIL COOLER BREAKS IN, A PROTECTIVE COATING EVENTUALLY FORMS ON THE COPPER TUBES AND THE LEACHING STOPS.

THE ENGINE ISN'T PAMAGED AND THE ELEVATED COPPER LEVELS GRAPUALLY DECREASE.

COPPER LEACHING FROM THE OIL COOLER INTO THE ENGINE OIL TYPICALLY HAPPENS WITH NEW ENGINES WITHIN THE FIRST TWO OIL CHANGE INTERVALS.

LEACHING CAN ALSO HAPPEN IN USED ENGINES...

- if the engine is overdue for an oil change.
- that have had a new oil cooler installed.
- if a different type of oil is used.

SO WHEN SHOULD YOU BE CONCERNED ABOUT ELEVATED COPPER LEVELS IN YOUR STRYKER'S ENGINE OIL?

IF YOUR STRYKER IS NEW OR HAS A NEW ENGINE AND IT GETS AN AOAP REPORT INDICATING INCREASED COPPER LEVELS, COPPER LEACHING FROM THE OIL COOLER IS LIKELY TO BLAME.

YOUR STRYKER'S ENGINE IS PROBABLY OK AND YOU CAN CONTINUE SUBMITTING AOAP SAMPLES EVERY SIX MONTHS OR 3,000 MILES, WHICHEVER COMES FIRST.



HOWEVER, IF THE VEHICLE OR ENGINE IS USED AND HAS EVER OVERHEATED. THE INCREASED LEVELS OF COPPER COULD BE CAUSED BY WORN BRONZE BUSHINGS AND BEARINGS OR A COMBINATION OF BOTH.

THAT'S WHEN YOU NEED TO BE CONCERNED ABOUT ENGINE DAMAGE AND FURTHER AOAP SAMPLING.



CHECK OUT P5 772 FOR INFORMATION ABOUT STRYKERS AND THE AOAP PROGRAM: https://www.logsa.army.mil/web2/archive/PS2017/772/772-06-08.pdf

TORQUE AWAY TRANSMISSION WOES



MECHANICS, IT'S VERY IMPORTANT TO APPLY JUST THE RIGHT AMOUNT OF TORQUE TO THE FILTER HOULGING AND DRAIN PLUG BOLTS ON THE AVLB'S TRANSMISSION.


TOO MUCH TORQUE CAN CAUSE CRACKS IN THE TRANSMISSION'S ALLUMINUM FILTER HOUSING AND STRIP THE DRAIN PLUG BOLT HOLE THREADS.

AVOID COSTLY
DAMAGE AND KEEP
COMBAT READINESS
HIGH BY KEEPING
THOSE BOLTS
TORQUED TO

THAT CAN LEAD
TO CATASTROPHIC
TRANSMISSION
FAILURE. A NEW
TRANSMISSION
WILL COST YOUR
UNIT NEARLY
\$75,000!

WHILE YOU'RE AT IT, MAKE SURE THE HOLES ARE FREE OF DEBRIS BEFORE TIGHTENING THE BOLTS. Over-tightening bolts can crack transmission filter housing and strip drain plug bolt holes





RUST BUSTERS TIP OF HE MONTH















MAKE A LIST OF ANY MISSING, BROKEN OR SOON-TO-BE EMPTY ITEMS.

THEN ADD THOSE ITEMS TO THIS HANDY SHOPPING LIST.






Lube oil/grease Power grinder

Scraping knife Shop vacuum

Shop vacuum accessories

Wire brush



Coveralls Ear plugs

Face shield Gloves

Gloves

Goggles/eye protection Respirator & cartridge

CPC Application

Applicator brush

Corrosion inhibiting compounds (CIC)

Petrolatum

Pressurized spray applicator

Rust inhibiting compound

Sealant

Solid film lubricant

Thread compound

Touch-Up Painting

Paint brush Wet film gauge





Cold Weather... WINTER STORMS: ARE YOU READY OR NOT?



WINTER WEATHER REQUIRES MORE PREPARATION AND MAINTENANCE FOR VEHICLES

PART OF THAT PREPARATION SHOULD INCLUDE WINTER SURVIVABILITY TIPS IN CASE OF EMERGENCIES!

OF COURSE, THE -10 TM IS YOUR FIRST STOP. THE SECTION ON OPERATION UNDER UNUSUAL CONDITIONS HAS INFO ABOUT STARTING, OPERATING AND MAINTAINING VEHICLES IN COLD WEATHER.

A VIDEO, PRODUCED BY THE U.S. ARMY COMBAT READINESS CENTER, IS A GREAT RESOURCE, TOO. IT SHOWS WHAT TO DO IF YOU'RE STRANDED IN A VEHICLE DURING WINTER.

PRACTICAL TIPS LIKE THESE COULD SAVE YOUR LIFE:

- Raise the hood and display a trouble sign, like a bright cloth tied to the side mirror or fastened at the top of a door.
- Make sure snow drifts or debris don't block the tail pipe.
- Stay in the vehicle unless you can see help within 100 yards.
- Crank the vehicle once every hour and run the heater about 10 minutes.

Watch the video here:

https://www.dvidshub.net/video/413415/stranded-vehicle LEARN ABOUT APPITIONAL WINTER PRIVING TIPS AT: https://safetu.armu.mil










AN UPDATE TO THE HMMWV PARTS LIST IS ON THE WAY, THANKS TO AN ALERT PS MAGAZINE READER WHO NOTICED A **DISCREPANCY** BETWEEN PART NUMBERS AND FIGURES.

TACOM SAYS ITEMS 6 THROUGH 15 IN FIG 209 OF TM 9-2320-387-13&P IN IETM EM 0323 (MAR 14) ARENT IN SYNCH WITH THE FIGURE CALL-OUTS. THESE ITEMS WILL BE RENUMBERED AS SHOWN HERE TO CORRESPOND WITH THE PROPER CALL-OUTS AT THE NEXT TM UPDATE.

IN THE MEANTIME, HERE'S HOW THE PARTS LIST SHOULD READ:



Item Number	ltem •	NSN
6	Frame section LH	2510-01-358-1178
6	Frame section RH	2510-01-357-8789
7	Self-locking nut	5310-01-548-1848
8	Flat washer	5310-01-121-1703
9	Bumper, front	2540-01-412-8610
10	Pin cotter	5315-00-012-0123
11	Plain nut	5310-01-569-6094
12	Shackle	4030-01-316-1551
13	Screw cap	5305-01-264-3602
14	Screw cap	5305-00-071-2071
15	Bracket mount	5340-01-106-2516

PS 792 13 NOV 18




Dear Editor,


We recently had a tire deflation problem with the two front tires on an FMTV while the electronic control unit (ECU) showed five flashing lights. We swapped out both tires with spares, but the tires continued to deflate.

We followed the troubleshooting guide in the TM and replaced all the central tire inflation system (CTIS) components, including the quick release valve (QRV), wheel valve, pressure switch, pneumatic control unit (PCU), ECU, CTIS seals and wiring harness.

Then we sprayed soapy water on all the supply lines and tire hoses to look for an air leak. We found no signs of a leak, but the deflation problem continued.



Finally, I decided to cut the zip ties that secure the front air hoses together in a tight bundle. This allowed them to unwind and hang free. Then I sprayed soapy water on the hoses again.




That did the trick! The soapy water bubbled up and made the leaks easy to detect. We replaced the front air hoses, and that fixed the deflation problem.

The moral of the story: when CTIS air hoses are tightly banded together, you can't always see or detect air leaks. Before you start replacing CTIS components, separate the tightly banded air hoses and check for air leaks first. This could save a lot of time and costly replacements!

Ricardo S. Iriarte Annville, PA

Editor's note: *Many thanks, Ricardo. Soldiers, don't forget to re-secure the lines after the repair.*






USE THE CORROSION CODE
"170-CORRODED/RUSTED"
REGARDLESS OF WHETHER
YOU'RE REPORTING MANUALLY
WITH DA FORM 2404 OR ONLINE
WITH DA FORM 5988-E.

ALL MAINTENANCE DEFICIENCIES, INCLUDING CORROSION, MUST BE REPORTED IN GCSS-A, FOLLOWING THE GUIDANCE IN DA PAM 750-8.

THAT WAY, YOUR CORROSION REPORT WILL GET RECORDED CORRECTLY AND PLAY A ROLE IN DEVELOPING FUTURE MAINTENANCE DECISIONS AND BUDGETS.

LMTV Hydraulic Tank NSN

Get a new hydraulic tank for the $2^{1/2}$ -ton LMTV with NSN 4320-01-645-5255. This is the correct NSN for *all* FMTVs, but Item 13 in Fig 125 of TM 9-2320-333-13&P (Jun 15) lists NSN 4320-01-504-5020 for the LMTV. That's wrong, so make a note until the TM is updated.



BEFORE AND AFTER THE DAY'S RUN, KEEP THESE CHECKS IN MIND TO KEEP YOUR BUFFALO MISSION-READY:

Fluid Warm Up

IN COLP WEATHER, LET THE POWER STEERING FLUID WARM UP BEFORE MOVING THE STEERING WHEEL (ABOUT 30 MINUTES).

FOLLOW THE CAUTION PLACARD ON THE INSTRUMENT PANEL:

DO NOT FORCE THE STEERING
WHEEL TO TURN WHILE
VEHICLE IS STATIONARY.

THAT WAY YOU'LL **AVOID** POWER STEERING LEAKS.

Easy Pull on Cable

YOU'VE GOT TO DRAIN THE AIR TANKS ON YOUR BUFFALO EVERY DAY AFTER OPERATION. IF YOU FORGET, MOISTURE BUILDS UP AND CREATES CORROSION THAT PLUGS UP THE ENTIRE AIR SYSTEM, INCLUDING BRAKE VALVES AND CYLINDERS. THAT CAN ALSO LEAD TO BRAKE FAILURE.

SO DRAIN WATER FROM THE PRIMARY AND SECONDARY AIR TANKS ON THE **DRIVER'S SIDE** OF THE VEHICLE.

THE TANK HAS THREE PULL CABLES.

JUST DON'T YANK ON THEM. THE ADDED STRESS WILL
EVENTUALLY BREAK A CABLE.

PULL ON THE CABLES JUST UNTIL YOU HEAR AIR COME OUT. THAT'S FAR ENOUGH. AND MAKE SURE YOU PULL STRAIGHT OUT ON THE CABLES. YANKING OR PULLING THE CABLES SIDEWAYS WEARS OUT THE PROTECTIVE SLEEVE AND EXPOSES THE METAL STRANDS.

EVENTUALLY, THE CABLE DETERIORATES AND BREAKS, ESPECIALLY IF IT'S YANKED ON EVERY DAY DURING CHECKS AND SERVICES!





AKE A QUICK
WALK THROUGH ANY
ENGINEERING BATTALION
AND YOU'LL SEE LOTS
OF CONSTRUCTION
EQUIPMENT WITH BUILT-IN
STARTING AIDS, THESE
AIDS HELP VEHICLE
ENGINES TURN OVER IN
COLD WEATHER.

BUT IF YOU'RE LOOKING FOR ONE OF THESE STARTING AIPS ON THE BACKHOE LOADER (BHL), YOU'RE OUTTA LUCK. THERE ISN'T ONE.

UNFORTUNATELY, SOME OPERATORS THINK IT'S OK TO GRAB A CAN OF ETHER SPRAY TO CREATE THEIR OWN. NOW, SAY IT ONCE, THEN SAY IT OVER AND OVER AGAIN:



DON'T EVEN THINK ABOUT HEADING BACK TO THE WORKBENCH, GRABBING A CAN OF ETHER SPRAY, AND GIVING IT A GO! SPRAYING ETHER IN YOUR BHL'S ENGINE WILL CRACK PISTONS, BEND RODS AND RUIN HEADS.

Personnel Risk

TO BRING THE POINT HOME, A WARNING DECAL IS MOUNTED ON THE STREET SIDE OF THE BHL:

EXPLOSION HAZARD -DO NOT USE ETHER

THERE'S AN IMPORTANT REASON FOR THE DECAL. THE BHL'S ENGINE MANIFOLD INTAKE HEATER IS JUST ON THE OTHER SIDE. THAT HEATER GETS OVEN HOT. SO A SPRAY OF ETHER WILL IGNITE AND TRAVEL RIGHT BACK TO THE ETHER CAN. THAT CREATES AN EXPLOSION THAT CAN CAUSE SEVERE BURNS, SCARS, BLINDNESS OR EVEN DEATH!

SO IF YOU'RE HAVING PROBLEMS STARTING YOUR BHL, KEEP YOUR HANDS OFF THE SPRAY CAN ETHER AND GRAB A MECHANIC INSTEAD.







WHEN OLD MAN WINTER
ARRIVES ON THE SCENE,
IT WON'T BE LONG
BEFORE SNOW, ICE AND
WIND START BATTERING
YOUR AIRCRAFT.

THAT'S WHY IT'S IMPORTANT TO PLAN, PREPARE AND TRAIN FOR COLD WEATHER OPERATIONS BEFOREHAND USING YOUR AIRCRAFT-SPECIFIC TMS.

FOR GENERAL COLD WEATHER INFORMATION, CHECK OUT CHAPTER 10 OF TM 1-1500-204-23-1, GENERAL AIRCRAFT MAINTENANCE.











Fact 1: Cold Fuel



WHEN DEALING WITH COLD FUEL AND AIRCRAFT, KEEP THESE GROUNDING POINTS IN MIND: 1. aircraft to ground

2. aircraft to fuel tanker 3. aircraft to fuel nozzle BEFORE REMOVING THE CAP!

FAST!



IT'S ALSO IMPORTANT TO REINSTALL THE FUEL CAP BEFORE REMOVING THE GROUND WIRE FROM AN AIRCRAFT.

OTHERWISE, SPARKS
CAN SHOOT BETWEEN
THE GROUNDING CABLE
AND THE AIRCRAFT.









FOR EXAMPLE, WHEN SERVICING A STONE COUR AIRCRAFT'S OIL SYSTEMS, NEVER FILL IT TO THE BRIM. THAT'S BECAUSE OIL EXPANDS AS IT HEATS UP AND YOU'LL BE CLEANING UP AN OVERFLOW MESS.

BECAUSE OIL
LEAKS ARE A
BIGGER PROBLEM
IN THE WINTER,
REGULARLY EYEBALL
CONNECTIONS, JOINTS
AND SEALS.





OLD MAN WINTER
DOES A NUMBER
ON SEALS, WHEN
COLD CONTRACTS
A SEAL, IT OPENS
THE DOOR FOR
LEAKS.

EVEN WORSE, MOISTURE
CAN SEEP IN AROUND SEALS
AND FREEZE, COLD TURNS
MOISTURE INTO ICE AND ICE
CUTS THE SEALS, CHECK
SEALS REGULARLY TO SEE
IF THEY NEED REPLACING.

PS MORE

Fact 4: Cold Batteries

COLD CAN AFFECT BATTERIES, BUT UNLESS THE TEMPERATURES DROP TO SUB-FREEZING LEVELS, SEALED LEAD-ACID BATTERIES (SLAB) OR NI-CAD BATTERIES SHOULD CONTINUE TO DO THEIR JOB.

HOWEVER, FREQUENT COLD STARTS WILL SHORTEN BATTERY LIFE.

THE H-GOM HAS TWO SLAB BATTERIES IN THE NOSE. THE HH-GOL HAS THE SLAB BATTERY IN THE QUAD BAY. AND THE UH-GOA/L HAS THE BATTERY IN THE CABIN BEHIND THE PILOT SEAT. IT COULD BE EITHER A NI-CAD OR SLAB BATTERY.





YOUR BEST BET IS TO BRING BATTERIES INSIDE FROM THE COLD IF SUB-FREEZING TEMPERATURES ARE PREDICTED. BEFORE STARTING YOUR AIRCRAFT ENGINES, TURN ON THE SEARCHLIGHT, LANDING LIGHTS OR SOME OTHER COMPONENT FOR 30 SECONDS. THAT WARMS UP THE BATTERIES AND HELPS GET THE ENGINE STARTED.


KEEP SLABS WARM. THE COLD CAN DRAIN THEIR CHARGE MUCH FASTER THAN IT DOES A NICKEL CADMIUM BATTERY.

WHEN BRINGING EITHER SLAB OR NICKEL-CAPMIUM BATTERIES INSIPE, STORE THEM IN SEPARATE AREAS. FUMES FROM A SLAB BATTERY CAN CAUSE A NICKEL-CAPMIUM BATTERY TO PISCHARGE.

ALWAYS STORE BATTERIES ON A SHELF OR ON TOP OF DUNNAGE BECAUSE BARE FLOORS WILL DRAIN THEM.







Fact 6: Cold Aircraft

KEEPING USE AIRCRAFT COVERS TO PROTECT EVERY PART OF YOUR AIRCRAFT.







IF YOU CAN'T COVER THE ENTIRE AIRCRAFT, AT LEAST COVER:


- the engine inlets
- exhaust openinas
- pitot tubes
- the main rotor head and tail rotor



NEVER TAKE COLD WEATHER FOR GRANTED!

PREPARE TO DO MAINTENANCE WITH THE PROPER CLOTHING TO KEEP WARM SO THE JOB GETS DONE RIGHT.





Mechanics, the leaf spring assemblies on the standard aircraft towing system (SATS), NSN 1740-01-575-5662, are experiencing excessive wear that can put the SATS in a non-mission capable status.

While not a safety issue, the distance between the vehicle frame and leaf spring assembly can exceed the design constraints over time. If that happens, the leaf spring assembly can rub against the drive train.

New leaf spring inspection criteria will be added to the SATS' TM 1-1740-221-13&P at the next update. In the meantime, here are the new criteria:

Inspection Conditions




- With the engine shut down, make sure the transmission is in park.
- Chock the vehicle tires.
- Only use standard measurements such as $^{1}/_{2}$ inch, $^{3}/_{8}$ inch, $^{9}/_{16}$ inch (+/- $^{1}/_{16}$ inch).
- Take measurements at the rear, outboard edge of the front leaf spring assembly on the driver and passenger sides where the springs enter the housing block shackle.

1. Measure vertically from the vehicle's frame to the point where the leaf spring assembly enters the rear housing block shackle.

2. Move the ruler forward five inches and measure vertically from the top of the leaf spring to the frame.

Leaf Spring Measuring



- **3.** Subtract the lesser measurement from the greater one. If the result is less than one inch, no further action is necessary. If the difference is one inch or greater or the leaf spring assembly touches the vehicle frame, go to Step 4.
- **4.** On the DA Form 2404 (manual) or 5988-E (electronic), enter a / status symbol with the following: "Left/right leaf spring assembly sag measures _____." Enter your measurement in the blank.

In the future, units should order and replace both the front left and front right leaf spring assemblies at the next 500-hour/semiannual service. Make sure you replace both assemblies at the same time.

Got Aviation Corrosion Questions?

Fighting corrosion is a daily battle. And in that fight, sometimes questions come up about how best to fight corrosion. To get answers, contact the aviation corrosion team by email: usarmy.redstone.rdecom-amrdec.mbx.amcom-corrosion@mail.mil

CREPS Reports Improve Readiness

Readiness is important to the warfighter. That's why TACOM provides a way for you to voice your concerns or comments about equipment or TMs. Just submit a Collaborative Readiness Problem Solving (CREPS) report. The website is:

https://gfis.tacom.army.mil/hd/default.cfm?p=nt&cz=128

Stay Connected with PEO Soldier

Got questions about PEO Soldier items? Check out their website at: http://www.peosoldier.army.mil/

Also check them out on social media:

https:twitter.com/PEOSoldier https://facebook.com/PEOSoldier https://flickr.com/peosoldier https://youtube.com/user/USArmyPEOSoldier



THE RQ-7B SHADOW UAV NEEDS ALL THE PROTECTION YOU CAN GIVE IT FROM RAIN, WIND AND DIRT. ITS **DELICATE PARTS** CAN BE DAMAGED BY **TOO MUCH EXPOSURE** TO THE ELEMENTS. THE **BEST PROTECTION**FOR ALL UAVS IS TO KEEP
THEM PARKED **INSIDE** WHEN
THEY'RE **NOT** FLYING,



THAT'S WHY IT'S A GOOD IDEA TO TAKE ALONG A TENT BIG ENOUGH FOR AT LEAST THREE SHADOWS.

THE TENT NOT ONLY PROVIDES A GOOD PLACE TO PARK SHADOWS, BUT ALSO GIVES YOU A PROTECTED AREA FOR MAINTENANCE AND PMCS.


IF YOU DON'T
HAVE A TENT, AT
THE VERY LEAST
KEEP SHAPOWS
COVERED WITH A
TARP. IF WIND'S
ARE STRONG OR
STORMS ARE
RAGING, FIND
SOMEPLACE
ENCLOSED TO
PARK SHAPOWS
TO PARVEYENT
DAMAGE.

ONE SHADOW COMPONENT THAT SHOULD BE LEFT OUTSIDE AS LITTLE AS POSSIBLE IS THE UNINTERRUPTABLE POWER SUPPLY (UPS) FOR THE UNIVERSAL AND PORTABLE GROUND DATA TERMINALS (UGDT AND PGDT).

THE
UPS IS
ESPECIALLY
SENSITIVE
TO WATER
AND DIRT.

MAKE SURE THE UPS IS OFF THE GROUND ON A PLATFORM TO PREVENT STANDING WATER FROM GETTING IN THE UPS.

IF A UGDT OR PGDT IS GOING TO BE SITTING OUTSIDE VERY LONG, COVER THE UPS TO PROTECT IT FROM THE ELEMENTS.



FOR MORE INFO ON PROTECTING YOUR SHADOW, SEE TM 1-1550-1689-23&P AND TM 1-1550-689-23&P.


JAMES BONDO in MOONBREAKER

(part 2)

































































































UOC Makes All the Difference







SMALL ARMS
REPAIRMEN,
THE UOC
(USABLE ON
CODE) MAKES
ALL THE
DIFFERENCE
WHEN YOU
ORDER PARTS
FOR YOUR
M240
MACHINE GUN,
MIG RIFLE OR
M4/M4A1
CARBINE.



SO WHEN YOU'RE LOOKING UP REPLACEMENT PARTS IN THE WEAPON'S -23&P, CHECK THE PART'S LIOC TO MAKE SURE IT'S THE RIGHT ONE FOR YOUR WEAPON.

SERIES OF NUMBERS AND/OR LETTERS NEXT TO THE PART'S PESCRIPTION. THE LOC TELLS YOU WHAT MODELS THE LETTERS AND NUMBERS

REPRESENT.

THE LOC IS A



Here are the M240 UOCs:

M240: G69 M240B: BB2 M240C: L04

M240D: BC2 M240E1: AG8

M240G: BC6 M240H: BN4

M240N: BJ8

Here are the M16 and M4 UOCs:

M16A2: AR8 M16A3: AW4 M16A4: AZ1 M4: AS1 M4A1: AY6 Small Arms...

DEGREASING AND SFL GO HAND-IN-HAND





WHEN A WEAPON'S PROTECTIVE COATING WEARS OFF, SFL COMES TO THE RESCUE.



BUT YOU MUST FOLLOW THIS SFL PROCEDURE OR YOU MAY BE HURTING MORE THAN HELPING YOUR WEAPON!



A WEAPON MUST BE THOROUGHLY DEGREASED AND INSPECTED FOR CORROSION AND DAMAGE BEFORE USING SFL.


A WEAPON SHOULD ALSO BE THOROUGHLY DEGREASED EVERY TIME YOU CHANGE LUBES. IF THE WEAPON IS CORRODED OR DAMAGED, IT MUST BE REPAIRED BEFORE USING SFL.

TO DEGREASE, USE MIL-PRF-680 TYPE II DRY CLEANING SOLVENT. NSN 6850-01-474-2317.











MUCH EASIER TO TOUCH UP NICKS, SCRATCHES AND SHINY SPOTS.





Small Arms...

Check Weapons and COMMS





Dear Editor,

Please emphasize to your readers the critical importance of inspecting weapons before transferring them to other units. And the receiving units also need to do their own inspections before letting weapons out of the arms room.

We've received several weapons that weren't up to 10/20 standards. In one case, a cleaning rod was stuck in the barrel. The weapon would've blown apart if fired!

WO1 Robert Mitchell ALARNG Editor's note: Yes, weapons should be inspected going and coming. Every weapon's -23&P TM lists the PMCS that should be done when a unit receives a weapon, new or old.

M16-Series Rifle, M4/M4A Carbine...

NEED A FRONT SIGHT TOOL? YOU HAVE CHOICES!

Dear Half-Mast, How do you get the tool to adjust and remove the M16 rifle and M4 carbine's front sight post?

SSG D.R.

Dear Sergeant,

Now you have two choices. In the past your support had to fabricate the tool following the instructions in WP 0030-2 in TM 9-1005-319-23&P. You can still go that route. Or you can order the tool with NSN 1005-01-660-5283 for \$35.



Dear Editor,

The M2A1 machine gun's TM 9-1005-347-23&P (Jul 11) gives the wrong info on using the breech lock selection tool.

The \widetilde{WP} 0033 00-4 says to retract the bolt until the barrel extension has separated no more than 1/16 inch from the trunnion block. This lets you use the breech lock selection tool to get the correct breech lock size.

The problem comes when the TM says to slowly release the retracting slide. That's wrong. You'll need to hold the retracting slide handle in place to maintain the 1/16-in separation until the right breech lock selection tool size has been determined.

If you do it the way the TM says, you could get the wrong reading.

SGT Nick Rucker NEARNG Editor's note: You're absolutely right, Sergeant.

This will be corrected in the next revision to the TM.

M2A1 Machine Gun... MISSING BARREL LOCKING SPRING NSN


Dear Editor,

The M2A1 machine gun's TM 9-1005-347-23&P doesn't list the NSN for the barrel locking spring or show its picture in the repair parts and special tools list (RPSTL).

Repairmen need to make a note in WP 0016 00-10 that they can order the spring with NSN 1005-00-726-6134. That way they won't have to order the entire barrel extension assembly.


Follow the procedure in WP 0016 00-10 to install the spring into the barrel extension assembly.

> James Wood JBLM, WA




Editor's note: Great tip, James. The M2 and M2A1 -23&Ps are being merged and this mistake will be corrected in the new TM.

DON'T LET BUFFER SUFFER!



If the buffer on your M240B or M240L machine gun suffers, so will your entire weapon. These checks spot buffer problems early:



- Measure the buffer plunger. It should protrude from the wear indicator lug a minimum of ⁹/₁₆ inch (14mm). If it doesn't, the buffer is loose from the buffer housing. Your weapon is NMC until the buffer is replaced.
- Check the buffer housing for peening, cracking or other damage, including missing finish from the stop above the buffer.
- from the stop above the buffer.

 Check the buffer shaft for bends, mushrooming, peening
- C until the buffer is bends, mushrooming, peening and cracks on the shaft's face.
- Check the shaft for oil residue. Work the buffer to check for fluid leakage. The buffer shaft should depress smoothly without chatter and return promptly when released.



FOLLOWING THESE
TIPS WILL KEEP
ME READY FOR
ACTION AND...

..That's the SATS Fact!



Dear Editor.

We've found these tips keep our Standard Automotive Tool Set (SATS) ready for action:

Pight corrosion by running A/C. We know PS has talked about how desiccants can help prevent corrosion doing a number on tools and other equipment stored inside SATS. But we've found the best way to beat corrosion is simply opening up SATS every week and running the A/C for 45 minutes. That does a good job drying up any moisture inside.




T'M GETTING
PRETTY WET
INSIDE HERE.
BETTER OPEN
MY DOOR
AND TURN ON
THE A/C OR
ELSE WE'RE
GOING TO
HAVE MIJOR
CORROSION
PROBLEMS!

• Use two people to slide out the generator. The generator is very heavy. If the stops on the slide rails fail, the generator could slide out right on top of you! That's bad for you and the generator. Wear gloves, too. Your hands need protection from the pinch points between the door frame and the front of the rails.

It's best to have one person pushing from the rear while the other pulls from the front. Do it slowly so the generator has no momentum. Don't depend on the rail stops to stop the generator.

Try to park the SATS on level ground. That makes it easier to slide the generator in and out safely.






- Give the generator air. Open the generator's two doors whenever it's running. That lets exhaust go outside instead of inside the trailer.
- Make sure everything is securely strapped down before hitting the road. You don't want large objects flying around inside the trailer. Every single item in the trailer should have its own ratchet strap with that strap tightly locked in place before you travel.


BE AN EXPENSIVE TRIP!






Pay special attention to the air compressor, tire jack and transmission jack. You sure don't want those heavy items bouncing around. It's easier if you strap the wheel table to the top of the transmission jack. They make a good fit.





 Before opening the door, make sure the steps are in the stow position. Otherwise, you can damage the door when you open it.



SSG Jason Firestine SPC Detreu Gregory Ft Bragg, NC

Editor's note: Those are, in fact, good SATS tips. Thanks.







HIMARS and M270A1 MLRS rocket exhaust can do a real number on the cable connectors. The exhaust is extremely corrosive. If it's allowed to do its worst, you'll soon get system faults and it becomes harder and harder to connect and disconnect cables.

THE EXHAUST BEFORE IT DOES A


CORROSION NUMBER ON US.

A little PM after firing can make short work of corrosion. Use a wire brush to rub off any corrosion from the outside of connectors. Then use a soft brush and isopropyl alcohol to clean inside the connectors. Pay special attention to the HIMARS' W519 and W520 and the MLRS' W19 and W420 cables. They usually have the most problems with corrosion.

FROM ALL THIS

ROCKET EXHAUST!

Use the cable second-chance (SAV-CONS) adapters. The adapters are fairly cheap—cables are not. If you bend the pins on an adapter, you can just put on another adapter and you're back in business. That's why it's a good idea for HIMARS and MLRS units to keep a stock of second-chance adapters. You don't want to take a chance damaging the cable connector because you have no adapter.






FORGET OUR CABLE

CONNECTORS!

HIMARS units can get more adapters free from the contractor with pseudo NSNs 0000-H0-000-0028 and 0000-H0-000-0029. MLRS units order the adapters with NSN 5935-01-155-9847 and NSN 5935-01-238-5896.

When cables become difficult to take off or you get system faults, first try changing the second-chance adapter. That often fixes the problem.




PS 792 45 NOV 18



DRAINING PREVENTS OVERNIGHT FREEZE DAMAGE TO THE LADS PLUMBING.

IF WATER FREEZES INSIDE THE LADS, IT CAN RUPTURE A SUBCOOLER OR WATER PUMP. IT CAN ALSO BURST PIPES AND VALVES.

THAT'S AN EXPENSIVE AND MESSY PROBLEM. SO YOU MUST RUN THE DRAIN CYCLE.




FOLLOW THE INSTRUCTIONS IN TM 10-3510-221-10 (JUL 08). WP 0016 TELLS YOU HOW TO PRAIN THE LAPS MOPEL C. WP 0017 COVERS THE LAPS MOPEL D.

MAKE SURE TO COMPLETE THE ENTIRE WORK PACKAGE FOR EACH MODEL. USE THESE GUIDELINES ALONG WITH THE TM...



- Flush water from the anti-foam and detergent hand pumps.
- Drain the water tanks. Disconnect the bright green utility hose and open the faucet.
- Even after you run the DRAIN CYCLE, a little water stays in the LADS. Drain leftover water in the water pumps, distillate pump and still by opening their ball valves (drain cocks).
 Make sure the valves are left open. That way freezing water has room to expand and won't crack pipes and valves. Note: Drain cycle can't be done manually.
- Also drain the 10-ft and 50-ft water supply hoses, the 5-ft and 50-ft drain hoses, the utility hose and the water supply pump.



is forgetting to drain the recycle system's distillate pump assembly particulate filter housings and subcooler. Check that all eight of its valves are


opened.

A common mistake

to drain (stem's will freeze and crack if not drained gs and weather, until the LADS is needed.

IMPORTANT!

PRAIN THE LAPS NOT ONLY
BEFORE TEMPERATURES
PROP TO FREEZING,
BUT ALSO BEFORE YOU
TRANSPORT OR STORE IT.
HAULING THE LAPS WITH
FULL WATER TANKS CAN
CAUSE THE TANKS TO CRACK.
STORING THE LAPS WITH
WATER IN IT ALSO SETS UP
A BREEDING GROUND FOR
BACTERIA.



SEP: By Soldiers, for Soldiers















YOU MAY BE SURPRISED TO LEARN THAT SOLDIERS HAVE A **YOICE** IN ARMY PURCHASING DECISIONS.

IN FACT, MORE
THAN 40 PERCENT
OF CURRENT
PROGRAM EXECUTIVE
OFFICE SOLPIER
(PEO SOLDIER)
EQUIPMENT BEGAN
IN THE SOLPIER
ENHANCEMENT
PROGRAM (SEP),

SEP suggestions have led to Army equipment additions







SEP HAS BEEN AROUND FOR 28 YEARS, TAKING A 'BUY, TRY, AND DECIDE" APPROACH TO RECOMMENDED PRODUCTS.

FOR EXAMPLE, THE MODULAR
AIRBORNE WEAPONS CASE, CLIP-ON
SNIPER NIGHT SIGHT, AND TACTICAL
COMMUNICATION AND PROTECTIVE
SYSTEM ALL STARTED AS
SEP RECOMMENDATIONS
FROM THE FIELD.

COMMERCIAL OFF-THE-SHELF (COTS), GOVERNMENT OFF-THE-SHELF (GOTS), OR NON-PEVELOPMENTAL ITEMS (NDIS) ARE ALL CANDIDATES FOR SEP EVALUATION AND IMPLEMENTATION.

THE RECOMMENDED ITEM OR EQUIPMENT SHOULD DO ONE OR MORE OF THE FOLLOWING:

- Improve ability to execute a combat mission
- Improve the current program of record of COTS/GOTS/ NDI products
- Assist in the refinement and/or generation of requirements. SEP identifies COTS/GOTS/NDIs capabilities. These can be evaluated during low-cost, low-risk evaluations. The data can help developers validate and approve an item.
- Bridge a capability gap
- Improve a combat platform interface.

SINCE PRODUCTS UNDER SEP CONSIDERATION ARE ALREADY COMMERCIALLY AVAILABLE, SAVINGS COME FROM A STREAMLINED ACQUISITION PROCESS AND REDUCED RESEARCH AND DEVELOPMENT COSTS.

NOW'S YOUR CHANCE TO MAKE A REAL DIFFERENCE NOT ONLY IN UNCLE SAM'S POCKETBOOK, BUT IN YOUR FELLOW SOLDIERS' LIVES.

IF YOU THINK THERE'S A TECHNOLOGY OR EQUIPMENT ITEM THAT THE ARMY SHOULD CONSIDER, VISIT: http://www.peosoldier.army.mil/sep/

READY TO TAKE THE PLUNGE? PRESS THE <u>SUBMIT AN ITEM</u> BUTTON AND FILL OUT THE FORM.

QUESTIONS?

usarmy.belvoir.peo-soldier. mbx.peo-soldier-g7-sep@ mail.mil

DATA PLATES: BUMP UP READINESS




RECENT ARMY AUDIT FOUND THAT **WOT** ALL EQUIPMENT IS BEING PROPERLY RECORDED AND REPORTED IN GCSS-ARMY.

ONE REASON FOR THIS IS THAT SOME EQUIPMENT DATA PLATES ARE MISSING, UNREADABLE OR INCLUDE WRONG DATA.

UNITS SHOULD FOLLOW THESE STEPS TO **RESOLVE** DATA PLATE ISSUES AND **IMPROVE** EQUIPMENT READINESS:

 During inventory, identify any equipment with missing, illegible or incorrect data plates.



2. Check the equipment TM to see if the data plate is a field-level replacement item that can be ordered through the normal supply process.



3. If it's ground equipment and data plates are not addressed in the TM, check with your nearest TACOM LAR, who will contact the equipment program manager to coordinate data plate replacement, if possible. To find your TACOM LAR, see Pages 14-15 in PS 759:

https://www.logsa.army.mil/web2/archive/PS2016/759/759-14-15.pdf

TACOM's Logistics Assistance Directorate is another resource at:

https://www.tacom.army.mil/ilsc/lad/

- **4.** To request night vision goggle data plates (AN/PVS-14, AN/PVS-7 and AN/AVS-6), email: usarmy.apg.cecom.mbx.lrc-night-vision-support@mail.mil
- 5. Alternatively, new data plates can often be made at depots at unit cost. For more info, see Letterkenny Army Depot's website at:

http://www.letterkenny.army.mil/UIDworks/howto.html Or email AMC at: usarmy.redstone.usamc.mbx.iuid@mail.mil



Dear Half-Mast,

I need to order OE-254 parts for our unit. The antenna mast group is NSN 5985-01-063-1574. I'm trying to find the mast section part that connects to the feed cone. It's the AB-24/GRC antenna element listed as Item 1 of TM 11-5985-357-23P (Jun 88). I've hunted high and low and gone over the TM with a fine-toothed comb, but I can't find an NSN for this part. Any tips?

SGT G.J.

Dear Sergeant,

Yup. I'm all about raising pointed antenna tips! Here's a couple: the TM misidentified some parts. The mast section part that connects to the feed cone assembly is the MS-116A antenna element, NSN 5985-00-199-8831.

The AB-24/GRC antenna element. NSN 5985-00-240-3720, is the

Half-Mast

The AB-24/GRC antenna element, NSN 5985-00-240-3720, is the antenna tip mast section part. For reference, see Pages 1-0 and B-2 of TM 11-5985-357-13 (Feb 91). Antennas up!

Aim for a Tender Touch









A TENDER TOUCH IS NEEDED WHEN YOU CONNECT AND DISCONNECT THE RADIO FREQUENCY CABLE (W2), NSN 5995-01-304-2026, ON YOUR SINCGARS VEHICULAR RADIO.

ROUGH HANDLING OR BLINDLY RAMMING N' JAMMING THE CABLE CAN BREAK OFF THE CONNECTOR PIN.

IF A PIN GETS STUCK AND BREAKS OFF INSIDE THE RT'S ANTENNA CONNECTOR OR THE POWER AMPLIFIER'S J2 CONNECTOR, YOU'LL BE SINGING THE BUSTED BLUES.


YOU'LL HAVE TO SEND YOUR SINCGARS TO SUSTAINMENT-LEVEL MAINTENANCE TO EXTRACT THE PIN.

IN OTHER WORDS, ONE MOMENT OF **ROUGH HANDLING** CAN TRANSLATE INTO A LOT OF **REPAIR TIME**, **BIG BUCKS** AND **MAJOR HASSLES**.

THE SAME CAUTION APPLIES TO THE CG-3855/VRC RADIO FREQUENCY CABLE, WHICH CONNECTS THE POWER AMPLIFIER TO THE VEHICULAR ANTENNA.

IF YOU'RE **TOO ROUGH**, THE CONNECTOR PIN COULD **BREAK OFF** AND GET STUCK INSIDE THE POWER AMPLIFIER'S JI CONNECTOR.






A GENTLE AND STEADY HAND IS THE KEY TO PRESERVING THOSE CONNECTIONS.




- Line up the keyhole on the cable connector with the key on the RT's antenna connector (or the power amplifier's J1 or J2 connector).
- **2.** Push the cable connector straight in.
- Turn the cable connector clockwise until it doesn't move any more.



AND HERE'S THE CORRECT WAY TO DISCONNECT THE CABLES...

- Turn the cable connector counter-clockwise until the keyhole on the cable connector lines up with the key.
- 2. Pull the cable connector straight out and off.



...WHEN
SERGEANT
SCHELL TOLD
ME TO PCMS
THE HMMWV
BEFORE
WE TOOK IT
OUT INTO
THE FIELD,
I REALIZED
HOW TO
IMPROVE THE
PROCESS...





HERE ARE A
FEW QUESTIONS
TO HELP YOU
GET STARTER:



- What is the problem with your equipment or error in your TM?
- What caused the problem?
- What is the solution to the problem or needed correction to the TM?
- What is the potential cost to the Army if the problem isn't corrected?
- What is the solution to the problem or the correction for the procedure in the TM?

ONCE YOU'VE OUTLINED THE PROBLEMS AND SOLUTIONS, IT'S TIME TO SUBMIT YOUR INFORMATION. DON'T WORRY ABOUT THE FORMAT. ONE OF OUR WRITERS WILL TAKE THE INFORMATION YOU PROVIDE AND WRITE THE ARTICLE IN THE PS STYLE.



WE'LL ALSO HAVE A SUBJECT MATTER EXPERT FROM THE RESPONSIBLE LCMC REVIEW THE INFORMATION, ALL PS ARTICLES ARE APPROVED BY AN ARMY AUTHORIZED PROPONENT BEFORE THEY ARE PUBLISHED.

MAKE SURE TO INCLUDE ANY HELPFUL PHOTOGRAPHS AS JPG ATTACHMENTS IN YOUR EMAIL. **DON'T** EMBED THE PICS IN A WORD OR POWERPOINT DOCUMENT, THOUGH. THAT **DEGRADES** THEIR QUALITY AND MAKES THEM **UNUSABLE**.


PS ARTISTS USE THOSE PICTURES AS TECHNICAL REFERENCES WHEN THEY ILLUSTRATE THE ARTICLE.

IF YOU CATCH A MISTAKE IN A TM, IT'S ALSO A GOOD IDEA TO SUBMIT A DA FORM 2028, RECOMMENDED CHANGES TO PUBLICATIONS AND BLANK FORMS.

WE SHOWED YOU HOW TO DO THAT ON PAGES 58-59 OF PS 779 (OCT 17).

ONCE YOUR ARTICLE AND DIGITAL PICTURES ARE READY, SEND THEM TO THIS ADDRESS: usarmy.redstone.logsa.mbx.psmag@mail.mil








ONCE YOU LOG IN, DO A SEARCH FOR MSD. THEN CHECK OUT THE APATS MILSUITE LIBRARY FOR THE PD TMDE AND MSD POCUMENTS AS WELL AS COURSES ON MILUNIVERSITY, YOU'LL NEED YOUR CAC TO GAIN ACCESS: https://www.milsuite.mil/

IF YOU NEED HELP, EMAIL THE MSD/ICE HELP DESK: apats@redstone.army.mil

OR GIVE THEM A CALL: 877-564-1137







GCSS-ARMY

OPERATES ON TACTICAL ENTERPRISE LOGISTICS SYSTEM (TELS) HARDWARE THAT IS WINDOWS 10-COMPLIANT AND MEETS TRUSTED PLATFORM MODULE (TPM) 2.0 REQUIREMENTS.

THE TELS HARDWARE COMPONENTS ARE ESTABLISHED IN THE ARMY STANDARD SUPPLY SYSTEM FOR REQUISITIONING. THIS REPUCES OVERALL SUSTAINMENT COSTS, WHILE ALSO SUPPORTING RAPID TECHNOLOGY "REFRESH" REQUIREMENTS.


IT ALSO ENHANCES THE UNIT'S CAPABILITIES BY ALLOWING THEM TO REQUISITION TELS COMPONENTS WITH THE STANDARD HARDWARE CONFIGURATION, A FIVE-YEAR WARRANTY WITH A 72-HOUR TURNAROUND, AND THE PRE-LOADING OF THE GCSS-ARMY SOFTWARE.






Computer system, digital (laptop), NSN 7010-01-663-4963






Computer system, digital (tablet) NSN 7010-01-662-5022



QUESTIONS? EMAIL VANESSA RAMAGLIA AT: vanessa.e.ramaglia.civ@mail.mil

CALL THE MISTBUSTERS!









MIL-STD-2073-1, DoD Standard Practice for Military Packaging (Jan 11)

Here, you'll find information about the standard processes for developing and documenting military packaging, which is different from commercial packaging. It covers preservation methods to protect materiel against corrosion caused by the environment, physical or mechanical damage and other dangers during storage, handling or shipment.

SB 746-1, Publications for Packaging Army General Supplies (Apr 79)

This document lists publications that relate to packaging and processing Army general supplies, except for maintenance and ammo pubs. It provides guidance on procuring, storing, handling, shipping, issuing, caring and preserving general supplies.

MIL-HDBK-773, Electrostatic Discharge (ESD)-Protective Packaging (Jun 05)

Look here for detailed guidance on handling, packaging or storing items that can be damaged by electrostatic discharge.

TM 38-700, Packaging of Materiel, Preservation (Dec 99)

In this document you'll find instructions for cleaning, drying, preserving, packing, blocking and bracing, cushioning, reinforcing, weatherproofing and marking to prepare material for shipment or storage.

TM 38-701, Packaging of Materiel, Packing (Dec 99)

Contains detailed information about the requirements for packing operations, including:

- use of exterior shipping containers; assembling items or packs in the container.
- anchoring, blocking, bracing and cushioning items or packages in containers.
- weatherproofing.
- strapping of containers.
- testing exterior packs palletization and unitization of loads.
- parcel post.

The TM also covers general exterior marking in accordance with MIL-STD-129.

DA PAM 700-32, *Packaging of Army Materiel* (Jan 08) This pub gives uniform Army packaging guidelines.

MIL-STD-129, Military Marking For Shipment and Storage (Feb 14)

Provides the minimum requirements for uniform military marking and procedures for their application. Use it for the application of military specific markings for items transported and stored within the military distribution system. Markings for commercial packaging are discussed in ASTM D 3951.



PS 792 59

MIL-STD-147, Palletized Unit Load (May 08)

This standard explains the methods, materials and techniques used in the formation of bonded palletized unit loads of military supplies on 40 x 48-in pallets. These instructions can be modified for use with different sized pallets.











NO COMMERCIAL REFRIGERANTS

On Page 51 of *PS* 787 in Step #5 under "Unit Instructions," the article stated that local purchase is authorized through LARs. That's *wrong*. Commercial purchase of all refrigerants is prohibited. They must be sole-sourced through DLA.

HEMTT A4. PLS A1 Distribution Manifold NSNs

Need a new distribution manifold for your HEMTT A4 or PLS A1 vehicle? Look no further. Each of the distribution manifolds below also come with installed solenoids:

Vehicle	Item	Fig	ТМ	UOC	NSN 4730-
PLS A1	1	768	9-2320-319-13&P	741, 751	01-670-7782
HEMTT A4 CBT	1	423	9-2320-326-13&P	L13	01-669-8492
HEMTT A4 (M977A4, M983A4, M985A4, M984A4 GMT)	1	423	9-2320-326-13&P	LH2, LH5, LH9, L10	01-667-3000
HEMTT A4 (M978A4, M983A4 LET, M984A4, M1120A4 LHS)	1	423	9-2320-326-13&P	LH4, LH7, L11, L14	01-564-7505

HEMTT Fuel Tank Repair Kits Get Makeover

The field repair kit for the HEMTT fuel tank sealant system, NSN 2540-01-577-2372, has changed. That kit contained a sealant with a shelf life that, when expired, required disposal of the entire kit. To avoid this waste, the kit now comes in two parts. Order the repair tools from the old kit with NSN 4940-01-661-4758. Order the sealant with NSN 8030-01-661-4763.

LTAS Cab Lift Cylinder NSN

Order a new front cab lift cylinder assembly for your M1078A1P2 LTAS with NSN 3040-01-665-1836 (PN 12505544-001). The old NSN 3040-01-567-2729 no longer appears on FED LOG, and the old part number crosses to a terminal NSN.

Now Showing: ESAPI Test Videos

Like any equipment, body armor needs to be inspected before use. For step-by-step videos showing the right way to do tap and torque tests on your enhanced small arms protective inserts (ESAPI), visit: https://www.dvidshub.net/video/473427/peo-soldier-armored-plate-tap-test-training

Would You Stake Your Life with on the Condition of Your Equipment?

PS 792 61 NOV 18

THE **BEST** SOLDIERS SOAK UP MAINTENANCE INFO LIKE A **SPONGE...**



...THEN SHARE WHAT THEY'VE LEARNED!

